



## ZX QUICK-START GUIDES

An overview of how to install the ZX Panel® cladding system

# Soffit Installation



- Cut ZX-2P2 to size and fit ZX-213 J Mould Cap to edge of panel facing away from the house



**ZX-2P2**  
ZX-2P2 Panel 2400 X  
1200 X 2mm  
- Powder Coated



**ZX-213**  
ZX-213 J-Mould Cap x 5.4M -  
Powder Coated



- Join ZX-2P2 panels with ZX-214 H-jointer



**ZX-2P2**  
ZX-2P2 Panel 2400 X  
1200 X 2mm  
- Powder Coated



**ZX-214**  
ZX-214 H-Jointer x 5.4M -  
Powder Coated

- Fix to Soffit Bearer at 600 centres (or as required)
- Fix using ZX-24 screws



### ZX-24

ZX-24 M12x25mm FH SQ  
Tek Screws T410 Hardened  
- 1000 per box